

## 3 Using the MC-5jr without the editor

The **MC-5jr** can be used without programming.

There are 3 Modes:


- Program-Mode
- Preset-Mode
- Scenes-Mode

### 3.1 Changing Modes

Press **Button 1** and **5** at the same time to enter **Menu**.



The **MC-5jr** LEDs will show **Green – Red – Green – Red – Green** to indicate you entered the **Menu**.




Select:

**Button 1** for **Program-Mode**: Buttons acts as programmed on the Editor.

**Button 2** for **Preset-Mode**: Button 1-5 are Preset 1-5 on Midi Channel 1.

**Button 3** for **Scenes-Mode**: Button 1-5 are Scene 1-5 on Midi Channel 1.



After selection the **MC-5jr** will reboot (all LEDs green, all LEDs red, all LEDs off).

Of course at any time, you can change between Modes.